

DSC: checking trouble light problem (yellow light)

To Silence any trouble conditions on the keypad, press the # key.

On LCD5500 full read out keypads:

Press the * then 2, yellow light flashes and the LCD will display the first trouble condition. Use the arrow keys to scroll through all trouble conditions, and the * key to select that trouble for more detail, press # key to exit.

On LED keypads, LCD fixed message keypads:

Press the * then 2, yellow light flashes and a number 1 thru 8 will come up on the display.

Light 1, Service required, press key 1 for more details, if number 1 light stays on the main battery backup needs replacing. If number 2 thru 8 comes on call for service.

Light 2, Power Off to alarm panel, (power off, breaker off, transformer bad or unplugged).

Light 3, Telephone Line Trouble, no phone line working on the alarm system phone jack.

Light 4, Failure to Communicate, on the last alarm the system could not make a call to the monitoring station, (this will only clear off after a successful alarm communication to the monitoring station).

Light 5, Zone Fault, press key 5 for more details, the zone light with fault will come on. A wireless device has not checked in, smoke det. missing, etc.

Light 6, Zone Tamper, press key 6 for more details, the zone with the tamper condition will come on. A wireless device has a cover not on, check the device cover.

Light 7, Wireless Device Low Battery, press key 7 for more details, the zone/s with a bad battery will come on, replace the zone device battery, then open door/window should clear this trouble.

If no zone light comes on after pressing key 7, then it is a wireless four button remote keyfob that needs new batteries (usually 2, 2025 batteries). Should you have 2 or 3 remotes it would be wise to just change the batteries in all of them.

Light 8, Loss of Clock, the main panel internal clock is not set, (set the clock).

To Set Clock: press * ,6, main code, 1, enter time (in military), then date, # to exit.
format: HH:MM MM/DD/YY